Autonics

ANALOG TIMER AT11DN/AT11EN

MANUAL



Thank you very much for selecting Autonics products.

For your safety, please read the following before using.

Caution for your safety

▼Please keep these instructions and review them before using this unit.

Warning Serious injury may result if instructions are not followed.

▲ Caution Product may be damaged, or injury may result if instructions are not followed.

★The following is an explanation of the symbols used in the operation manual.

A caution: Injury or danger may occur under special conditions.

The following is an explanation of the symbols used in the operation manual.

A caution: Injury or danger may occur under special conditions.

The following is an explanation of the symbols used in the operation manual.

The following is an explanation of the symbols used in the operation manual.

The following is an explanation of the symbols used in the operation manual.

The following is an explanation of the symbols used in the operation manual.

The following is an explanation of the symbols used in the operation manual.

The following is an explanation of the symbols used in the operation manual.

The following is a first the following is a first the operation of the symbols used in the operation of the opera

∧ Warning

 In case of using this unit with machineries (Nuclear power control, medical equipment, vehicle, train, airplane, combustion apparatus, entertainment or safety device etc), it requires installing fail-safe device, or contact us for information required.

It may result in serious damage, fire or human injury

2. This unit must be mounted on panel.

It may give an electric shock.

- Do not connect terminals when it is power on.
 It may give an electric shock.
- Do not disassemble and modify this unit, when it requires.
 If needs, please contact us.

It may give an electric shock and cause a fire.

▲ Caution


- 1. This equipment shall not be used outdoors.
 - It might shorten the life cycle of the product or give an electric shock.
- 2. Please observe specification rating.


It might shorten the life cycle of the product and cause a fire.

- Do not use the load beyond rated switching capacity of Relay contact.
 It may cause insulation failure, contact melt, contact failure, relay broken fire etc.
- In cleaning the unit, do not use water or an organic solvents.It might cause an electric shock or fire that will result in damage to the product.
- Do not use this unit at place where there are flammable or explosive gas, humidity, direct ray of the sun, radiant heat, vibration, impact etc.

It may cause a fire or mechanical trouble.

Do not inflow dust or wire dregs into inside of this unit. It may cause a fire or mechanical trouble.






■ Time specifications

Time range	Time unit	Time setting range
0.5		0.05 to 0.5
1.0	1	0.1 to 1.0
5	sec	0.5 to 5
10		1 to 10
0.5	min	0.05 to 0.5
1.0		0.1 to 1.0
5		0.5 to 5
10		1 to 10
0.5	hour	0.05 to 0.5
1.0		0.1 to 1.0
5		0.5 to 5
10		1 to 10
0.5	10h	0.05 to 0.5
1.0		0.1 to 1.0
5		0.5 to 5
10		1 to 10

			494450	494454	
Model			AT11DN AT11EN		
Control time setting range		ng range	0.05sec to 100hour(Max. time)		
Power supply			• 100-240VAC(50/60Hz), 24-240VDC • 12VDC(Option) 90 to 110% of rated voltage0		
Allowable voltage range0		rangeu	• 100-240VAC : Approx. 4VA, • 100-240VAC : Approx. 4.5VA.		
Power consumption		ion	• 100-240VAC : Approx. 4VA, 24-240VDC : Approx. 1.3W • 12VDC : Approx. 0.9W		
Return time0			Max. 100ms		
Min. input START input		tT input	50ms		
signal width	RESET input				
	INHIBIT input				
Input	START input		[No-voltage input] Shot-circuit impedance : Max. 1kΩ		
	RESET input			voltage: Max. 0.5V	
	INHI	BIT input	Open-circuit impedance : Min. 100		
Control	Con-	Туре	Time limit 2c	Time limit 1c, Instantaneous contact 1c	
output0	tact	Capacity	250VAC 3A resistive load	NO:250VAC 3A resistive load NC:250VAC 2A resistive load	
Repeat err	or		Max.	±0.3%	
Setting err	or		Max. ±5% ±0.05sec		
Voltage er	ror		Max. ±0.5%		
Temperature error		r	Max. ±2%		
Insulation	resista	nce	Min. 100MΩ (500VDC mega between all terminals and case)		
Dielectric :	Dielectric stength		2000VAC 50/60Hz for 1 minute(Between all terminals and case)		
Noise strength			±2kV the square wave noise(pulse width:1عم) by the noise simulator		
Vibration	Mecl	nanical	0.75mm amplitude at frequency of 10 to 55Hz in each of X, Y, Z directions for 1 hours		
	Malf	unction	0.5mm amplitude at frequency of 10 to 55Hz in each of X, Y, Z directions for 10 minutes		
	Mecl	nanical	300m/s2 (Approx. 30G) 3 times at X, Y, Z direction		
Shock	Malf	unction	100m/s2 (Approx. 10G) 3 times at X, Y, Z direction		
	Mecl	nanicalD	Min.10,000	0,000 times	
Relay	Elec	ctrical	Min.100,000 times (250VAC 3A at resistive load)	Min.100,000 times (NO:250VAC 3A at resistive load NC:250VAC 2A at resistive load	
Ambient temperature		ture	-10 to 55°C (at non-freezing status)		
Storage te	mperat	ure	-25 to 65°C (at non-freezing status)		
Ambient h	umidity		35 to 85%RH		
Weight			Approx. 100g		
Approval			91		
AT11DN RESET START INHIBIT	1		CONTACT : 250VAC 3A RESISTIVE LOAD INHIBIT	CONTACT: NO:250VAC 3. NC:250VAC 2. S 6 7 RESISTIVE LO 9 9	
	I[SOURCE		SOURCE :	
		100-24	0VAC 50/60Hz	100-240VAC 50/60Hz	



Input signal condition

1. Relay contact input:

Please use gold-plated switches with good contact assurance and short bounding time for contact input.


2. NPN open collector transistor input:

The characteristic of transistor shall be :

Vceo: Min. 25V Ic: Min. 10mA Icbo: Max. 0.2μA.


Residual voltage: Max. 0.5V

Please maintain 50ms for signal width of relay contact and solid state input(START, RESET, INHIBIT)




Caution for using


AT11DN/AT11EN are designed as power circuit without using a transformer.
 Therefore the power of sensor is supplied by isolation transformer which is not grounded in the secondary side as shown in (Fig.1).




Please use the terminal @ as the common terminal as shown in (Fig.3).
 If use the terminal ® as common terminal as shown in (Fig.2), it might cause damage to inner circuit of AT11DN/AT11EN Timer.



When one input signal is inputted to plural timers, be sure to avoid the wiring as shown in (Fig.4). Otherwise, the short-circuit current will flow to cause breakage.



- 4. Please connect DC power input after checking polarity of power.
- When apply the power, please apply rating power at the moment by switch, relay etc. Otherwise it might cause malfunction.
- Do not use this product for long time. It may cause shorten life cycle of Timer due to heat inner electric component.
- When supply the power to the timer, connection as shown in (Fig.6). It might cause malfunction due to leakage current though R and C. Please connect R and C as shown in (Fig.7) to prevent malfunction as shown in (Fig.7).



- Do not wire START, RESET, INHIBIT signal input line with power line, high voltage line in parallel.
- It might cause malfunction if change the setting time, time range or operation mode during unit operating. Please change the setting time, time range or operation mode after cut the power off.
- When test dielectric voltage and insulation resistance of the control panel with this unit installed.
 - The Please isolate this unit from the circuit of control panel.
 - Please make all terminals of this unit short-circuited.
- 11. Do not use this unit at below places.
 - ①Place where there are severe vibration or impact.
 - Place where strong alkalis or acids are used.
 - 3Place where there are direct ray of the sun
 - Place where strong magnetic field or electric noise are generated.
- 12. Installation environment
 - 1 It shall be used indoor
 - ②Altitude Max. 2000m
 - 3Pollution Degree 2
 - Installation Category II
- *It may cause malfunction if above instructions are not followed.